MEERKAT™

TRADER®

MESW
MESWFAN
MESWHEAT
MESWLIGHT
MESW20
MESW32
MESW32OVEN
MESW32HOB
MESWI
MESWBPR
MESWDP
MESWDP20
MESWDP20HOB
MESWDP20OVEN
MESW3*

See currrent catalogue for further detail

MESW switch mechanism are used in conjunction with Flat Cat, Puma and Cougar switch plates

Note: MESWC (Cat's Eye) switch mechanism are used in conjunction with Snow Leopard, Leopard and Cheetah switch plates

*Multiple print options available - see catalogue or website for further detail.

Cleaning Guide:

Spraying cleaning products on to electrical products is not recommended.

It is important to ensure that switches are turned off before cleaning.

Do not use any cleaning sprays - only wipe down with damp cloth or rub with dry cloth. (Do not use an abrasive cloth as it may scratch the plastic).

Do not use harsh chemical cleaners as these can break down the plastic and cause it to crack.



Meerkat Range of Rocker Switch Mechanisms

For use in conjunction with FLAT CAT, PUMA and COUGAR

- MESW - approved to AS/NZS3133.
- Designed to clip into Flat Cat, Puma and Cougar switch plates, also fits all Trader Ranges and many others.
- Uses brass tunnel terminal that have the screws backed out for easier installation of cabling. Switches are single pole two way with looping terminal and suit 4 x 1.5mm^2 cables with 4.1mm bore.
- Slotted head terminal screws, and backed out for easy installation.
- Covers, plates and dollies are made from UV stabilised polycarbonate to avoid discolouring to yellow.
- ^SBL100W on some Standard Meerkat Mechs.
- Please check availability.
- Covers, plates and dollies are made from UV stabilised polycarbonate to avoid discolouring to yellow.
- Please check availability.



Catalogue Number	Description
^MESW	Switch Mechanism 10AX 16A 250V ac White
^MESWFAN	Switch Mechanism 10AX 16A 250V ac Labelled Fan White
^MESWHEAT	Switch Mechanism 10AX 16A 250V ac Labelled Heat White
^MESWLIGHT	Switch Mechanism 10AX 16A 250V ac Labelled Light White
MESW20	Switch Mechanism 16AX 20A 250V ac White
MESW32	Switch Mechanism 32A 250V ac White
MESW32OVEN	Switch Mechanism 32A 250V ac Labelled OVEN White
MESW32HOB	Switch Mechanism 32A 250V ac Labelled HOB White
^MESWI	Intermediate Switch Mechanism 10AX 250V ac White
*MESWBPR	Switch Mechanism Bell Press Return 10AX 16A 250V ac White
^MESWDP	Double Pole Switch Mechanism 10AX 250V ac White
MESWDP20	Double Pole Switch Mechanism 20A 250V ac White
MESWDP20HOB	Double Pole Switch Mechanism 20A 250V ac Labelled HOB White
MESWDP20OVEN	Double Pole Switch Mechanism 20A 250V ac Labelled OVEN White
^MESW3	Switch Mechanism 3-Position 10AX 250V ac White

- For colours and finishes see Meerkat Rocker Matrix on following pages.
- Colours available: White (Standard), Black (BK), Matt White (MW), Matt Black (MBK) and Green (G). Check for availability.

The MEERKAT Rocker Switch Mechanism (MESW) was previously and is universal to all Flat Cat, Puma and Cougar switch plates.

FLAT CAT™ PUMA™ COUGAR™

Certification Number:
MESW: GMA-501682-EA / GMA-501835-EA / GMA-508487-EA MESWBPR: GMA-508434-EA

GSM Electrical (Australia) Pty Ltd
Level 2, 142-144 Fullarton Road, Rose Park SA 5067
P: 1300 301 838 | E: service@gsme.com.au
www.gsme.com.au

100% AUSTRALIAN TRADER OWNED & OPERATED

10 Yr Warranty TRADER

Standard Range of Rocker Switch Mechanisms

FLAT CAT™ PUMA™ COUGAR™



PART NO.		DESCRIPTION	SNOW LEOPARD	CLOUDED LEOPARD	LEOPARD	FLAT CAT	PUMA	COUGAR
MESW		Switch Mechanism 10AX/16A 250V~				✓	✓	✓
MESWBK		Switch Mechanism 10AX/16A 250V~ Black				✓	✓	✓
MESWMW		Switch Mechanism 10AX/16A 250V~ Matt White				✓		
MESWMBK		Switch Mechanism 10AX/16A 250V~ Matt Black				✓		
MESWFAN		Switch Mechanism 16A 250V~ (Labelled Fan)				✓	✓	✓
MESWHEAT		Switch Mechanism 16A 250V~ (Labelled Heat)				✓	✓	✓
MESWLIGHT		Switch Mechanism 16A 250V~ (Labelled Light)				✓	✓	✓
MESWGR		Switch Mechanism 10AX/16A 250V~ Green				✓	✓	✓
MESW20	ALL GREEN BASED MECHS ARE 16AX/20AMP STANDARD	Switch Mechanism 16AX/20A 250V~				✓	✓	✓
MESW20BK		Switch Mechanism 16AX/20A 250V~ Black				✓	✓	✓
MESW20MW		Switch Mechanism 16AX/20A 250V~ Matt White				✓		
MESW20MBK		Switch Mechanism 16AX/20A 250V~ Matt Black				✓		
MESWDP20		Double Pole Switch Mechanism 20A 250V~				✓	✓	✓
MESWDP20BK		Double Pole Switch Mechanism 20A 250V~ Black				✓	✓	✓
MESWDP20HOB		Double Pole Switch Mechanism 20A 250V~ (Labelled HOB)				✓	✓	✓
MESWDP20HOBBK		Double Pole Switch Mechanism 20A 250V~ (Labelled HOB) Black				✓	✓	✓
MESWDP20OVEN		Double Pole Switch Mechanism 20A 250V~ (Labelled OVEN)				✓	✓	✓
MESWDP20OVENBK		Double Pole Switch Mechanism 20A 250V~ (Labelled OVEN) Black				✓	✓	✓
MESW32		Switch Mechanism 32A 250V~				✓	✓	✓
MESW32BK		Switch Mechanism 32A 250V~ Black				✓	✓	✓
MESW32MW		Switch Mechanism 32A 250V~ Matt White				✓		
MESW32MBK		Switch Mechanism 32A 250V~ Matt Black				✓		
MESW32OVEN		Switch Mechanism 32A 250V~ (Labelled Oven)				✓	✓	✓
MESW32HOB		Switch Mechanism 32A 250V~ (Labelled HOB)				✓	✓	✓

ME = Meerkat SW = Switch C = Cat's Eye BK = Black MW= Matt White MBK = Matt Black SV = Silver G = Green

Standard Range of Rocker Switch Mechanisms

FLAT CAT™ PUMA™ COUGAR™



PART NO.		DESCRIPTION	SNOW LEOPARD	CLOUDED LEOPARD	LEOPARD	FLAT CAT	PUMA	COUGAR
	MESWI	Intermediate Switch Mechanism 10AX 250V~				✓	✓	✓
	MESWIBK	Intermediate Switch Mechanism 10AX 250V~ Black				✓	✓	✓
	MESWIMW	Intermediate Switch Mechanism 10AX 250V~ Matt White				✓		
	MESWIMBK	Intermediate Switch Mechanism 10AX 250V~ Matt Black				✓		
	MESWDP	Double Pole Switch Mechanism 10AX 250V~				✓	✓	✓
	MESWDPBK	Double Pole Switch Mechanism 10AX 250V~ Black				✓	✓	✓
	MESWDPMW	Double Pole Switch Mechanism 10AX 250V~ Matt White				✓		
	MESWDPMBK	Double Pole Switch Mechanism 10AX 250V~ Matt Black				✓		
	MESW3	Switch Mechanism 3-Position 10AX/16A 250V~				✓	✓	✓
	MESW3BK	Switch Mechanism 3-Position 10AX/16A 250V~ Black				✓	✓	✓
	MESW3MW	Switch Mechanism 3-Position 10AX/16A 250V~ Matt White				✓		
	MESW3MBK	Switch Mechanism 3-Position 10AX/16A 250V~ Matt Black				✓		
	MESW3AOM	Switch Mechanism 3-Position 10AX/16A 250V~ AUTO/OFF/MAN				✓	✓	✓
	MESW3AOMBK	Switch Mechanism 3-Position 10AX/16A 250V~ AUTO/OFF/MAN, Black				✓	✓	✓
	MESW3AOMMW	Switch Mechanism 3-Position 10AX/16A 250V~ AUTO/OFF/MAN, Matt White				✓		
	MESW3AOMMBK	Switch Mechanism 3-Position 10AX/16A 250V~ AUTO/OFF/MAN, Matt Black				✓		
	MESW3SOO	Switch Mechanism 3-Position 10AX/16A 250V~ SENSOR/OFF/ON				✓	✓	✓
	MESW3SOOBK	Switch Mechanism 3-Position 10AX/16A 250V~ SENSOR/OFF/ON, Black				✓	✓	✓
	MESW3SOOMW	Switch Mechanism 3-Position 10AX/16A 250V~ SENSOR/OFF/ON, Matt White				✓		
	MESW3SOOMBK	Switch Mechanism 3-Position 10AX/16A 250V~ SENSOR/OFF/ON, Matt Black				✓		
	MESW3UOD	Switch Mechanism 3-Position 10AX/16A 250V~ UP/OFF/DOWN				✓	✓	✓
	MESW3UODBK	Switch Mechanism 3-Position 10AX/16A 250V~ UP/OFF/DOWN, Black				✓	✓	✓
	MESW3UODMW	Switch Mechanism 3-Position 10AX/16A 250V~ UP/OFF/DOWN, Matt White				✓		
	MESW3UODMBK	Switch Mechanism 3-Position 10AX/16A 250V~ UP/OFF/DOWN, Matt Black				✓		
	MESWBPR	Switch Mechanism Bell Press Return 10AX/16A 250V~				✓	✓	✓
	MESWBPRBK	Switch Mechanism Bell Press Return 10AX/16A 250V~ Black				✓	✓	✓
	MESWBPRMW	Switch Mechanism Bell Press Return 10AX/16A 250V~ Matt White				✓		
	MESWBPRMBK	Switch Mechanism Bell Press Return 10AX/16A 250V~ Matt Black				✓		

ME = Meerkat SW = Switch C = Cat's Eye BK = Black MW= Matt White MBK = Matt Black SV = Silver G = Green