



PUBIG4MB PUBIG4MBBK PUBIG5MB

*See current catalogue for further detail







Cleaning Guide:


Spraying cleaning products directly on to electrical switches or power points (sockets) is not recommended.

It is important to ensure that switches are turned off before cleaning.

Do not use any cleaning sprays - only wipe down with damp cloth or rub with dry cloth. Do not use an abrasive cloth as it may scratch the plastic.


Do not use harsh chemical cleaners as these can break down the plastic and cause it to crack.


Do not wash the cover plates in water over 60°C.



Puma BIG4 and BIG5 Fixed Power Points - Mounting Blocks

- 25mm high mounting block to suit PUBIG4 and PUBIG5.
- Made from UV stabilised polycarbonate to avoid discolouring to yellow.
- BIG4 Mounting block available in White or Black
- · BIG5 Mounting block only available in White
- BIG4 and BIG4 Mounting blocks include backing plates for situations where fully enclosed insulation is required.





Catalogue Number	Description
PUBIG4MB	4 Gang Mounting Block, for PUBIG4B
PUBIG4MBBK	4 Gang Mounting Block, Black, for PUBIG4BK
PUBIG5MB	5 Gang Mounting Block, for PUBIG5



Level 2, 142-144 Fullarton Road, Rose Park SA 5067 P: 1300 301 838 F: 1300 301 778 E: service@gsme.com.au www.gsme.com.au



