

10MM-J34BF-4G & 10MM-J34BF-4GP INSTRUCTION MANUAL

1. Connect masthead amplifier as close to antenna/s as practical.
2. Connect relevant coaxial cables.
3. Set Input Selection switch to position '1' or '2' to suit antenna setup (default position 1)
4. Install power supply and injector between wallplate and TV at the outlet connected to the 'power pass' leg of the splitter indicated as a red line..

IMPORTANT Install masthead amplifier before connecting power injector to outlet and power supply to mains.

