


**CLIPSAL**<sup>®</sup>

by **Schneider** Electric



**Expressaire Exhaust Fan**

**6220-0**



**Airflow**<sup>®</sup>

Installation Instructions

## Installation Instructions

### 6220-0

All fans should be installed by a suitably qualified person in accordance with AS/NZ3000.2000 and relevant building codes. Disconnect supply before making any electrical connections.

For best results, provision should be made for return air to enter the room on the opposite side. In some instances a return air grill/vent may be required.

### Installation:

1. This card can be used as a template for making appropriate fan mounting hole size.
2. Cut hole of the required diameter (290mm dia.) in the desired position in the ceiling.
3. Attach earthed plug base on joist as near as possible to mounting hole.
4. Remove fan blade by unscrewing central knob anticlockwise (refer fig. 1).
5. Remove screw hole plugs from duct mounting arm (refer fig. 1).
6. Support fan while connecting 3-pin plug.
7. Insert fan into opening in the ceiling. Push the three brackets back through the duct (refer fig.2). Pull screws down and tighten until duct is firmly fixed to the ceiling. Plug must be accessible after installation.
8. Replace fan blade making sure that shaft cross bar engages fan blade hub correctly.
9. Insert screw cover plugs over three mounting screws.
10. Ducting must be no closer than 250mm to chimney flue or other similar exhaust flue (refer fig.3).
11. If the supply cord is damaged it must be replaced by the manufacturer or its service agent, or a similarly qualified person, in order to avoid a hazard.

### Warning

The appliance is not intended for use by children or infirm persons without supervision. Children should be supervised to ensure they do not play with the appliance. Appliance is intended to be mounted on external wall only.




### Cleaning:

1. Ensure fan is unplugged or switched off at mains.
2. Remove fan blade by unscrewing central knob.
3. Wash fan blade in warm soapy water, rinse clean and dry fan blade.
4. Fan duct may be wiped down with moist soapy cloth.
5. Replace fan blade.

### Template

#### Centre Hole

Use this template to mark mounting hole for the fan. Use a nail or similar object to anchor the template at the centre hole, then insert a pencil through the template at the 290mm marking and scribe a circle.



**DO NOT INSTALL WITHIN 120cm OF STOVE**

290mm diameter

## Warranty

The benefits conferred by this warranty are in addition to all other rights and remedies in respect of the product, which the consumer has under the Trade Practices Act and similar State and Territory laws.

The original purchaser of this Clipsal Exhaust Fan is provided with the following warranty, subject to the following conditions. Clipsal by Schneider Electric warrants this product for a period of three (3) years from the date of purchase for all parts defective in workmanship or materials.

All defective parts will be replaced free of charge. The following exclusions do not preclude the purchaser from those statutory rights consumers have under the Trade Practices Act or similar State and Territory laws.

### Replacement Warranty Conditions:

1. This warranty is only valid for appliances installed according to the manufacturer's instructions.
2. This appliance must not be modified or changed in any way.
3. All wiring must be carried out by a licensed electrician or similarly qualified person and must be connected to the voltage requirements as specified on the ratings label.
4. The manufacturer does not accept liability for any direct or consequential damage, loss or other expense arising from misuse or incorrect installation and operation of the appliance.
5. Warranty will only be given on appliances where proof of purchase date is provided, e.g. original invoice or copy.
6. As a record of your purchase, please fill out the following details and file this information with your purchase invoice.

Clipsal Exhaust Fan model number: \_\_\_\_\_

Serial number: \_\_\_\_\_

Purchased from: \_\_\_\_\_

Date of purchase: \_\_\_\_\_

**Schneider Electric (Australia) Pty Ltd**

Contact us: [clipsal.com/feedback](http://clipsal.com/feedback)

National Customer Care Enquiries:

**Tel 1300 2025 25**

**Fax 1300 2025 56**

**clipsal.com**

Schneider Electric (Australia) Pty Ltd reserves the right to change specifications, modify designs and discontinue items without incurring obligation and whilst every effort is made to ensure that descriptions, specifications and other information in this catalogue are correct, no warranty is given in respect thereof and the company shall not be liable for any error therein.

© 2012 Schneider Electric. All Rights Reserved.  
Trademarks are owned by Schneider Electric Industries SAS or its affiliated companies.