



GETTING STARTED

Congratulations on the purchase of your new Ventair SDCRC 'VARIO' remote.
To get started simply install the batteries and follow the pairing instructions below.

PAIRING

Step 1: Remote only (no wall control): Turn the isolation switch 'OFF' for minimum of 1 minute.

With wall control (SDC3SPWC): Ensure the fan speed dial and the light switch are both set to the 'OFF' position for a minimum of 1 minute.










Step 2: Turn the isolation switch or speed dial / light switch on and within 2 seconds, press and hold the fan off (⏻) button for 3-4 seconds until you hear a 'beep, beep' sound to indicate pairing succeeded.

Pairing a second remote with your fan: One fan can be paired with a maximum of two remote controls, to pair a second remote, follow the above pairing procedure with the new handpiece.

Removing a remote from your fan memory: To remove one remote from your fan memory, simply re-pair the one you wish to keep. This action will overwrite the data for the second remote in your fan memory.

OPERATION

PLEASE NOTE: Features may vary by fan model.

-  Fan Off (light remains unchanged)
-  Adjust the fan speed from 1 (lowest) to 6 (highest).
-  Breeze Mode: Varies the fan speed to create a natural breeze effect.
-  Light ON/OFF.
-  Forward/Reverse adjusts the direction of blade rotation (Summer / Winter).
-  Adjusts light colour (Cool, Natural and Warm).
-  Adjusts the light intensity up to maximum brightness.
 Adjusts the light intensity down to minimum brightness.
-  One, Four or Eight hour Fan Off Timer.



TROUBLESHOOTING:

No Indicator Light, Intermittent Operation or Remote only Works Close-up:

Dead or low batteries, replace with high quality lithium AAA batteries to extend the period between changes.

Fan is unresponsive - Loss of pairing/sync:

Re-pair the remote as outlined above.

Spyda DC intermittently changes speed:

Without Light models:

The Fan Speed Dial **must** remain on the **HIGH** setting.

With Light Models:

Light Switch **ON:** Fan Speed Dial must be set to **OFF** or **HIGH**.

Light Switch **OFF:** Fan Speed Dial must remain on the **HIGH** setting.

WARRANTY

OUR GOODS COME WITH GUARANTEES THAT CANNOT BE EXCLUDED UNDER THE AUSTRALIAN CONSUMER LAW. YOU ARE ENTITLED TO A REPLACEMENT OR REFUND FOR A MAJOR FAILURE AND COMPENSATION FOR ANY OTHER REASONABLY FORESEEABLE LOSS OR DAMAGE. YOU ARE ALSO ENTITLED TO HAVE THE GOODS REPAIRED OR REPLACED IF THE GOODS FAIL TO BE OF ACCEPTABLE QUALITY AND THE FAILURE DOES NOT AMOUNT TO A MAJOR FAILURE.

IMPORTANT WARRANTY INFORMATION. PLEASE READ AND OWNER TO RETAIN.

THE FULL WARRANTY POLICY MUST BE READ PRIOR TO SUBMITTING A WARRANTY CLAIM.
THE VENTAIR PRODUCT WARRANTY IS SUBJECT TO THE BELOW.
THE CUSTOMER WILL NOT GAIN THE BENEFIT OF THIS WARRANTY WITHOUT FIRST LODGING A CLAIM.

BEFORE USE: Check to ensure there is no visible damage. Should there be any damage, contact Ventair support via email: support@ventair.com.au or ph: (03) 9775 0556 to discuss.

WARRANTY PERIOD: This product is covered against manufacturing defects by a two (2) year limited warranty. If a defect covered by this Warranty appears, and the Customer wishes to make a claim under the terms of this Warranty, the Customer must within 7 days of detection of the alleged fault contact Ventair. During this period Ventair will, at our discretion supply parts or provide a replacement unit of the same or comparable model.

IN HOME WARRANTY SERVICE: Not applicable.

COMMERCIAL USAGE: All products have a maximum one (1) year warranty when used in a commercial setting and 'in home' service is not applicable.

PLEASE NOTE:

- The Ventair warranty Terms & Conditions available at www.ventair.com.au/warranty must be fully satisfied.
- The claimed fault must not be the result of normal wear and tear.
- The product must only be used for the purposes specified in this manual.
- The unit or relevant part must not have been physically damaged, involved in an accident, modified, subject to misuse, neglect or abuse.
- In the event of a difference between the online and supplied warranty terms, Ventair will, at its discretion, determine which version applies.

THIS WARRANTY DOES NOT COVER:

- Damages or faults not arising from defects in the Ventair product materials or workmanship.
- The replacement of supplied batteries, these are considered consumable items.

If you suspect a manufacturing defect, lodge a warranty by visiting www.ventair.com.au/warranty

You will need to provide the following information:

- Proof of purchase
- The nature of the fault
- The brand and model number of the unit
- Supporting evidence